



In order to update to the 5.5.273 firmware version,
please install firmware **4.5.224-LTS-FM.fw** first.

Then proceed to STEP 2 once installation is completed.

