



NEURALYZER

OPERATION GUIDE

NDI[®]

BirdDog NEURALYZER performs a factory reset on any compatible BirdDog Eyes series camera. It is designed to reset all customizations to the unit in the case of a lost IP address, Web UI password or networking difficulties. NEURALYZER requires BirdDog Eyes firmware v2.8 or above.

Please disable any 3rd party virus protection software before operating BirdDog NEURALYZER.



1. Plug your BirdDog Eyes camera directly into your computers Ethernet port, and select the valid Ethernet adapter from the drop-down list.

2. Press RESET CAMERA SETTINGS. This will 'arm' NEURALYZER. It will wait in this state until it finds a BirdDog Eyes camera to reset

BirdDog | NEURALYZER ✕

Select Network Adapter

Ethernet 2 ▼

RESET CAMERA SETTINGS

Listening for camera to Reset ✓

Camera Found - XX:XX:XX:XX:XX - A200 ✓

Network and user settings reset to default ✓

Camera will now reboot to default settings in your network... ✓

3. Re-power your BirdDog Eyes camera, during the bootup sequence it will look for an 'armed' NEURALYZER, if it is discovered the network settings of the BirdDog Eyes camera will be set to default (IP Address, Name, Password)

4. Once the camera is found, its serial number and product description will appear in the UI followed by prompts that the settings have been reset and camera is rebooting