



# Firmware Update Instructions

## BirdDog PLAY

This document provides instructions on updating the PLAY firmware.

### What You'll Need

- 1 x BirdDog PLAY firmware update .zip file.
- 1 x BirdDog PLAY device.

### Procedure

#### System Firmware Update

This update is a single-step update performed from the BirdUI.

- a. Download and unzip the firmware file.
- a. Log into the PLAY BirdUI. The default password is 'birddog'.
- b. Navigate to the SYSTEM/SYSTEM UPDATE section.
- c. Click the CHOOSE FILE button, navigate to the downloaded folder, select the contained .fw file and click the UPDATE button.  
**NOTE:** This process may take up to 5 minutes and will require the unit to reboot. DO NOT power off the unit while this process completes.
- d. After the process reports as complete, allow 2 minutes for PLAY to reboot and then refresh your browser.
- e. If you wish to use the BirdUI, you'll need to log in again.
- f. The update process is now complete.

### Support Resources

BirdDog are committed to your success with our products and we have a team of global support engineers ready to help you. Should you need further assistance, please do not hesitate to reach out.

Email us at [help@birddog.tv](mailto:help@birddog.tv)

This is a high priority email address and is received by support, engineering and management. We are here to help!